

ID IDENT 4000

RFID and Barcode Reader



Contents

Disclaimer.....	3
1. Preface	4
1.1. Product introduction	4
1.2. Product feature	4
2. Product appearance.....	5
2.1.1. OVERALL INTRODUCTION	5
2.1.2. PRODUCT SIZE CHART	6
3. Product parameters	8
3.1. General parameter	8
3.2. Recognition parameter	8
3.3. Electric parameter	9
3.4. Work environment.....	9
4. Interface definition	10
4.1. RS485 & wiegand interface definition	10
4.2. Ethernet interface definition.....	11
5. Device configuration	12
6. Installation method.....	15
7. Access scenario application	16
7.1. Using scenario diagram	16
7.2. Access control system wiring diagram	17
8. Attention	18
9. Contact info.....	18

Disclaimer

Before using the product, please read all the contents in this Product Manual carefully to ensure the safe and effective use of the product. Do not disassemble the product or tear up the seal on the device by yourself, or iDTRONIC will not be responsible for the warranty or replacement of the product.

The pictures in this manual are for reference only. If any individual pictures do not match the actual product, the actual product shall prevail. For the upgrade and update of this product, iDTRONIC reserves the right to modify the document at any time without notice.

Use of this product is at the user's own risk. To the maximum extent permitted by applicable law, damages and risks arising from the use or inability to use this product, including but not limited to direct or indirect personal damage, loss of commercial profits, iDTRONIC will not bear any responsibility for trade interruption, loss of business information or any other economic loss.

All rights of interpretation and modification of this manual belong to iDTRONIC

1. Preface

Thank you for buying the ID IDENT 4000 QR/barcode reader provided by iDTRONIC.

Reading this document carefully can help you understand the functions and features of this device, and quickly master the use and installation of the device.

1.1. Product introduction


The ID IDENT 4000 QR/barcode reader was a specially designed product for access control, which has various output interface, support wiegand and RS485, can connect to the traditional access controller. It also support Ethernet output interface, with built-in relay module.

1.2. Product feature


- A. Scan QR/barcode & reading card all in one.
- B. Fast recognition, high accuracy, can reach 0.1s the fastest.
- C. Easy to operate, more easy to debug with the humanize tool.
- D. Built-in relay module, can connect to the access system directly.

2. Product appearance

2.1.1. OVERALL INTRODUCTION




2.1.2. PRODUCT SIZE CHART



2.1 back view



2.2 side view



2.3 front view

3. Product parameters

3.1. General parameter

General parameter	
output interface	RS485, wiegand, Ethernet, relay
indicating method	Red,green, blue, white indication light Beep
imaging sensor	300,000 pixel CMOS sensor
max. resolution	640*480
supported operating systems	Windows (XP, 7, 8, 10)
installation method	Wall mounted type
product dimensions	132*88*21mm
recognition window size	60mm*56mm
product material	Imported PC & tempered glass

3.2. Recognition parameter

QR code recognition parameter	
sybologies	QR, PDF417, CODE39, CODE93, CODE128, ISBN10,ITF,EAN13 etc
supported decoding	mobile phone screen/ printed barcodes
reading disteance	15.9mm - 75.68mm(QRCODE: 15mil)
reading accuracy	> 7mil
reading speed	100ms per time (average), support reading continuously
reading direction	Tilt±59.5° rotation±360° deflection±63.5° (70 character 15milQR)
FOV	Horizontal 72.4° vertical 54.2° FOV 84.8° (70 character 15milQR)

RFID parameter	
type	ISO 14443A,ISO 14443B protocol
operation method	read UID, read the sector of M1 card
frequency	13.56 Mhz
distance	< 5cm

3.3. Electric parameter

The power input can be provided only when the device is connected properly. If the device is plugged in or unplugged while the cable is live (hot plugging), its electronic components will be damaged.

Make sure that the power is turned off when plugging and unplugging the cable.

Poor power supply, too short interval power off and on operation may cause the device cannot work in a stable and normal status. It is necessary to keep the power input stable. After turning off the power input, it need to takes more than 2 seconds to turn on the power input again.

Electric parameter	
working voltage	DC 12V – 24V
working current	100mA (12V typical value)
power consumption	1,2W (12V typical value)
relay	DC 30V/1A

3.4. Work environment


work environment parameter	
ESD protection	±8kV (air discharge) ±4kV (direct discharge)
working temperature	-20°C - 70°C
storage temperature	-20°C - 70°C
relative humidity	5% - 95% (no condensation, under normal temperature)
ambient light	0-80000Lux (Non direct sunlight)

4. Interface definition


4.1. RS485 & wiegand interface definition

Pin10	Pin9	Pin8	Pin7	Pin6	Pin5	Pin4	Pin3	Pin2	Pin1
POW	GND	SIGN	NC	COM	NO	WG_D1	WG_D0	485A	485B

wiegand wiring diagram



RS485 wiring diagram




4.2. Ethernet interface definition

Pin10	Pin9	Pin8	Pin7	Pin6	Pin5	Pin4	Pin3	Pin2	Pin1
POW	GND	SIGN	NC	COM	NO	TX-	TX+	RX-	RX+

ID IDENT 4000 interface	Pin4	Pin3	Pin2	Pin1
Network cable color	Orange	Orange white	Green	Green white

ID IDENT 4000 Ethernet model directly leads four network cable pins, and can be connected to four of the standard eight-core network cables according to the color. The network cable uses the 568B type connection method. Refer to the table below and connect the cables according to color.

Wiring diagram (network device)



5. Device configuration


Use the IDENTconfig tool to configure the device, which can be download from our official website

 IDENTconfigv2.3.17.exe

(For more information about the configuration tool, please refer to the IDENTconfig user manual).

Configure the server address as the step shows:

Step 1: select language and device




Step 2: select output method




The screenshot shows the 'VguangConfigV2.3.17' window. At the top, there is a 'Set Password:' field with the value '1234567887654321'. To its right are two buttons: '→ Next' (highlighted with a red box and labeled '4') and '→ Main'. Below the password field is the 'Work mode' section with two radio buttons: 'Ordinary' (selected, highlighted with a red box and labeled '1') and 'Develop'. Under 'Ordinary', there is an 'Output' section with three radio buttons: 'RS485/232', 'Wigan', and 'Ethernet' (selected, highlighted with a red box and labeled '2'). Below the 'Output' section is the 'Development mode' section with two radio buttons: 'Protocol' (selected) and '485 one more'. A note below it says 'Note: it takes effect under the development mo'. At the bottom is the 'WIFI/Ethernet/2G output set' section (highlighted with a red box and labeled '3') with four radio buttons: 'TCP', 'TCP protocol', 'HTTP/HTTPS' (selected), and 'HTTP protocol/HTTPS protocol'. A red box labeled '4' is also around the '→ Next' button.

Step 3: configure the server address and the transfer action.



The screenshot shows the 'VguangConfigV2.3.17' window. At the top, there is a 'Set Password:' field with the value '1234567887654321'. To its right are two buttons: '→ Return' and '→ Main'. Below the password field is a tabbed interface with four tabs: 'Scan set', 'Advanced', 'Swipe', and 'Net'. The 'Net' tab is selected. On the left side of the 'Net' tab, there is a list of checkboxes: 'SuccessAction', 'FailAction', 'TCP/UDPPara' (highlighted with a red box and labeled 'configure the transfer behaviour'), 'HttpPara', 'HeartSet', 'IP Mode', and 'MAC address' (highlighted with a red box and labeled 'configure heartbeat (only TCP) or static/dynamic IP'). To the right of these checkboxes is a 'TCP/UDPPara' section with three input fields: 'Address:' (containing '192.168.1.1', highlighted with a red box and labeled 'configure TCP or HTTP server address'), 'Port num:' (containing '8080'), and 'Receive timeout(<=5):' (containing '2'). On the right side of the window, there are four buttons: 'Config code' (highlighted with a red box and labeled 'click here to generate configuration QR-code'), 'Save', 'Reset Password', and 'Exit'. Below these buttons is a label 'QR Code Position'.

Step 4: use the device to scan the config QR code





6. Installation method

The product using CMOS image sensor, the recognition window should avoid direct sun or other strong light source when install the scanner. The strong light source will cause the contrast in the image too big to decoding, the long term exposure will damage the sensor and cause the device failure.

The recognition window are using tempered glass, which has good transmission of the light, it also a pressure resistance, but still need to avoid scratching the glass by some hard object, it will affect the QR code recognition performance.


The RFID antenna was in the underside of the recognition window, there should have no metal or magnetic material within 10cm when installing the scanner, or it will affect the card reading performance.

			
1.fix the holder on the 86 box	2.Tighten up the holder with 2 M4*20 screws	3.Fix the product on the metal holder	4.Tighten up the product with 1 M3*6 screw from bottom


7. Access scenario application

The scenario is for the ID IDENT 4000 Ethernet device.

7.1. Using scenario diagram



7.2. Access control system wiring diagram



Note: access control solution introduction

1. Scanner connect with network, upload the scanned QR data to the specified server.
2. The server judge the authority when received the QR data.
3. If the QR code matches the door open condition, it will return the scanner a value.
4. When the scanner receive the returned value, it will output relay signal, control open the door.

8. Attention

1. The equipment standard is 12-24V power supply, it can get power from the access control power or power it separately. Excessive voltage may cause the device to fail to work normally or even damage the device.
2. Do not disassemble the scanner without permission, otherwise the device may be damaged.
3. For Ethernet scanner, it is necessary to ensure a good network environment, otherwise it may be unable to communicate with the server.
4. The installation position of the scanner should avoid direct sunlight. Otherwise, the scanning effect may be affected. The panel of the scanner must be clean, otherwise it may affect the normal image capture of the scanner. The metal around the scanner may interfere with the RFID magnetic field and affect card reading.
5. The wiring of the scanner must be firm. In addition, ensure the insulation between the lines to prevent the equipment from being damaged by a short circuit.
6. The output of the scanner is a switch signal. In an access control scenario, it can be connected to the original access control system according to the normally open or normally closed connection method of the original access control system.

9. Contact info

iDTRONIC GmbH
Ludwig-Reichling-Straße 4
67059 Ludwigshafen
Germany

E-Mail: info@idtronic-wellfit.de Web:
www.idtronic-wellfit.de

Phone: +49 621 6690094-0

Fax: +49 621 6690094-9